

A. CONNECTION FOR WINCH MODELS:

DWM 8000 HD
DWM 12000 HD
DWM 13000 ST

B. CONNECTION FOR WINCH MODEL: DWM 12 000 HDI

C. CONNECTION FOR WINCH MODELS:

DWM 8000 HD EN
DWM 10000 HD
DWM 12000 HD EN
DWM 13000 HD
DWM 13000 HD EN
DWM 13500 HD EN
DWT 14000 HD
DWT 15000 HD
DWT 16800 HD
DWT 18000 HD
DWT 20000 HD
DWH 9000 HD
DWH 12000 HD
DWH 15000 HD

D. CONNECTION FOR WINCH MODEL: DWTS 12000 HD

E. CONNECTION FOR WINCH MODELS:

DWM 3500 ST
DWH 3000 HD
DWH 3500 HD
DWH 4500 HD
DWH 4500 HDL

F. CONNECTION FOR WINCH MODELS:

DWM 2000 ST
DWM 2500 ST


G. CONNECTION RADIO CONTROL FOR WINCH MODELS:

DWM 2000 ST
DWM 2500 ST


H. FOR WINCH MODELS:

DWM 2000 YP, DWM 2500 YP AND DWM 3500 YP
FOLLOW THE DIAGRAM H.


A




B




C




D




E



F



G



H

